



Spare Indicator LEDs:
On-Indicating LEDs For Future
Expansion Breaker

SMS Enclosure Panel Assembly Wiring View

PN 3123	Document No. 980038020	
Date: 10.13.2020	Rev. 001	
By: K. Teichman	Scale:	Sheet: 1 of 1

BLUE SEA
SYSTEMS
4600 Ryzex Way
Bellingham, WA 98226
p: 360.738.8230
www.blueseasystems.com

Icon Key

-  In-Line Fuse Holder
-  Quick Connect Junction